

DESCRIPTION

CS1-RL(F) controller has been designed simple and low cost with high accuracy measurement, display, control or communication (Modbus RTU mode) such as pulse(Frequency) or AC Frequency.

☑ The innovation feature is auto-range input from 0.01Hz~ 100KHz(~140KHz in option). The display resolution will be auto-changed to show the highest according to input frequency.

They have been designed optional 1 of 3 kinds for 1 Relay, 1 Analogue or 1 RS485 port with flexible display function such as max/mini hold, PV hold relative PV.....etc that very useful in testing equipment and others. Please refer to the detail description on pages 2/38~7/38.

FEATURES

- Accuracy: $\pm 0.005\%$; Display range: 0~99999; Auto-range with Decimal Point auto changed according to input frequency.
- 1 relay, 1 Analogue output or RS 485 communication port can be selected one in option
- Relay for Hi / Lo energized with Start Delay / Hysteresis / Energized & De-energized Delay / Relay Energized Latch...etc functions
- EMC, EMI, LVD Approved & RoHS



[CS1-RL LINEARLY LINE SPEED / RPM CONTROLLER]

- Measuring RPM / Linearly line speed / Frequency AUTO RANGE 0.01~100KHz / ~140KHz(optional) / Contact, NPN, PNP, Voltage pulse can be switch on rear of meter.

[CS1-F FREQUENCY CONTROLLER]

- Measuring Frequency AUTO RANGE 0.01~100KHz / ~140KHz(optional) / Voltage pulse or sine wave(specify).

APPLICATIONS

Models

- **CS1-RL** Motor & Machinery / Testing Equipments for Measuring, Alarm or Communication with PC/PLC
☑ On line testing station for appliance, check points of PCB as so on.
- **CS1-F** Switch Boards / Testing Equipments for Measuring

Functions

- **Safety & Protection** Hi/Lo alarm and latch(H_{HLd} / L_{oHLd})
- **Testing & Measuring** Front Key functiond for Maximum/Minimum hold(M_{AXHd} / M_{INHd}), PV hold(P_{uHLd}), Relative PV/Tare/ Δ PV(R_{ELPu})
- **Remote Monitoring** RS485 communication port, Display function(R₅₄₈₅)

FUNCTION DEFINE

Character Symbol

A b C d E F G H i J K L M
 R b [d E F G H i J L n
 n o P q r S t U v W X y Z
 n o P q r S t U v W X y Z
 1 2 3 4 5 6 7 8 9 0 / .
 1 2 3 4 5 6 7 8 9 0 / .

Input Range & Mode


Input Range & Mode

The meter has been designed very wide input range from 0.01Hz~100.00KHz(Option: 0.01Hz~140.00KHz) that can cover almost any application for frequency measuring. User doesn't need to specify the input range.

Especially, they do not set the scale to relate the input range. Users are just set the measuring type(PuLgP) in [rPUL GrOUP]. The display of meter will show the value that user wants to show such as RPM, Linearly Line Speed or Frequency. Please refer to the description of Display Function.

Input mode Switchable

NPN / PNP / Voltage Pulse / Mech. Contact and amplitude can be switched by switches on rear of meter.



*The excitation supply of sensor can not be changed. Please specify in ordering code.

Display Functions

Multi-Display function

Programmable: [LSPd] / [rPn] / [rPS] / [Hz] / [kH?]

The meter has designed for multi-purpose. User can set the display purpose in [PuLgP] of [rPUL GrOUP] such as [LSPd](Linearly Line Speed), [rPn](RPM), [rPS](RPS), [Hz](Hz), [kH?] (kHz) that the meter will display according to the input and setting to calculate. The meter will show the relation parameters as below,

- [LSPd]: Pulse/rotation([PPr]), Engineer Units ([rPn] / [rPS] / [Hz] / [kH?]), Diameter of rotor([rAte])
- [rPn] / [rPS]: Pulse/rotation([PPr])

Factor function:

Settable range: 0.001~9.999

Display = Value of math with setting x Factor

The display can be proportioned by factor.

The typical application is compensation for gear ratio.

Auto-range function:

Programmable: [AUto] / [SEn] / [rAnUL]

- [AUto](Auto range): The decimal point will be auto changed according to the input frequency so that keep the display in the highest resolution.

Ex.: RPM of Motor: 7200RPM , Encoder: 1000ppr

The meter setting

[PuLgP]: [rPn], [PPr]: [1000],

[rAnUL]: [AUto]

(7200rpm x 1000ppr) / 60 = 120.000kHz

Frequency range is from 0~120.000kHz

The table is between input and display as below,

Freq. Input	Display	
0Hz	[0.0000] RPM	Auto change to keep highest resolution
166.65Hz	[9.9999] RPM	
1666.5Hz	[99.999] RPM	
16.665kHz	[999.99] RPM	
16.666kHz	[1000.0] RPM	
120kHz	[1200.0] RPM	

The input goes down to

166.65Hz [9.9999] RPM (Auto change)

- [SEn](Semi-Auto range): The decimal point will be auto changed according to the input frequency to keep the display in the highest resolution, but it must be under setting position of decimal point. It's possible to show "[ouFL](overflow)", if the input frequency is too high to makeover the display range.

Ex.: RPM of Motor: 7200RPM , Encoder: 1000ppr as same as above,

The meter setting

[PuLgP]: [rPn] ; [PPr]: [1000]

[rAnUL]: [SEn] ; [dP]: [0.00]

The table is between input and display as below,

Freq. Input	Display	
0Hz	[0.0000] RPM	Auto change to keep highest resolution
166.65Hz	[9.9999] RPM	
1666.5Hz	[99.999] RPM	
16.665kHz	[999.99] RPM	
16.666kHz	[ouFL] RPM	
120kHz	[ouFL] RPM	

The input goes down to

16.665kHz [999.99] RPM (Auto change)

In the case of input, the [**dP**] should set **0.0** to display full range of RPM and to get higher resolution in lower RPM.

- **MANUL** (Manual range): The decimal point will be fixed according to the setting of [**dP**]. The meter will show **ouFL** (overflow), once the input goes over the frequency that is relative 99999.

Ex.: RPM of Motor: 7200RPM , Encoder: 1000ppr as same as above,

The meter setting

[**PuLdY**]: **rPn** ; [**PPr**]: **1000**

[**rAnGE**]: **MANUL** ; [**dP**]: **0.00**

The table is between input and display as below,

Freq. Input	Display	Fix decimal point resolution
0Hz	0.00 RPM	
166.65Hz	9.99 RPM	
1666.5Hz	99.99 RPM	
16.665kHz	999.99 RPM	
16.666kHz	ouFL RPM	
120kHz	ouFL RPM	

The input goes down to

16.665kHz **999.9** RPM

In the case of input, the [**dP**] should set **0.0** to display full range of RPM.

Time out function

Programmable: **AUTO** / **MANUL**

In the case of low frequency, the meter can not to identify that is low frequency and no input until the next pulse input. Sometimes, it takes a long period.

The meter builds in a time out function to cut out the display to be "0".

There are two modes **AUTO** / **MANUL** can be programmed as below,

- **MANUL** (Manual): There is a period named **TO** (input time out) can be set from 0.0sec~999.9sec. The display will be "0", once the next pulse doesn't input during the setting time.
- **AUTO** (Auto): The display will be "0", once the next pulse doesn't input during the time that gave by formula of meter's firmware. Generally, the auto time out is 4 times of 1/ frequency of last input frequency.

Max / Mini recording

In order to review & trace the drifting PV, the meters will keep the values of maximum and minimum in **USER LEVEL** during power on.


The maximum and minimum can be reset by front key function. Please refer to the operation on description as below.

orange LED will be bright during power on, until

Maximum Hold or Minimum Hold for PV

When the [**dSPLY**] function in [**INPUT GROUP**] set to be **MAXHd** (Max. Hold) or **MINHd** (Mini. Hold), that the meter will still display the values of PV in maximum (or minimum) and the relative square manual reset by front key in **USER LEVEL** or Down Key function has been done. The meter will update immediately new maximum(minimum) values after press Down Key to reset.


Please paste the sticker **M.H** on the right side of orange square LED to identify the status of display.



PV(Present value) Hold

When the [**dSPLY**] set to be **PVHld** (PV Hold) function in [**INPUT GROUP**], that display will be hold & kept, and the relative green LED will be bright, when user press Down Key, until press Down Key again.

Please paste the sticker **ECI PV.H** on the right side of green square LED to identify the status of display.



Remote display by RS485 command

In past, The meter normally receive 4~20mA or 0~10V from AO card or BCD card of PLC. We built-in a new solution by RS485 remote display function which it can save costs of AO and wiring connecting to PLC simultaneously.

When the [**dSPLY**] function set to be **RS485**, the LED display no longer relative to the input signal then the PV screen will show the data from RS485 command.

Low Cut


Settable range from -19999~+29999 counts.

The users can set a value here to cut the display value to show "0".

- If the setting value is positive, it expressed the PV will be 0 which it's within the range of absolute value;


PV < I Setting value I, the display will be 0

EX: Low Cut is set for 0.50, if the display is from -0.50~+0.50, that will be 0.



- If the setting value is negative, it expressed the PV will be X which it's under the setting value; $PV < \text{Setting value}$, the display will be X(Setting value).

EX: Low Cut is set for -0.01, if the display is < -0.01 , and all the display will be -0.01.




Digital Fine Adjustment

Settable range from 0~99999 ;

Users can get "Fine Adjustment PV" by front key on the meter for higher points, and if the user want to show the current input signals that "Just Key-In" the value.

Especially, the [PUSPn] is not only in span of PV, but also any higher point for [PUSPn]. The meter will be linearization automotively for full scale.

The adjustment can be cleared in function [SCLEr].



*Please make sure that the [PUSPn] should be over 50% of input range. That may be made bigger error in span, if the interval is too narrow.

Reading Stable Functions

Average Display update

Settable range: 1~99 times;

Jittery Display caused by the noise or unstable signal. User can set number to average the readings to get smoothly display.

Remark: The higher average setting will impact the response time of Relay and Analogue output slower.

The meter's sampling is 15cycle/sec. If the [AUC](Average) set to be 3, the meter will express the sampling 3 readings and calculating the average then update the display once. At meantime, the display update will be 5 times/sec.

Average set to be 3


Sample 1	Sample 2	Sample 3	Sample 4	Sample 5	Sample 6	
Display Update Value = (Sample 1 + Sample 2 + Sample 3)/3			Display Update Value = (Sample 1 + Sample 2 + Sample 3)/3			

Digital filter

Settable range from 0(None)/1~99 times.

The digital filter can reduce the influence of spark noise caused by magnetic of coil.

If the values of samples are over digital filter band(fix in firmware and about 5% of stable reading) 3 times (Digital Filter set to be 3) continuously, the meter will admit the samples and update the new reading. Otherwise, it will be as treat as a noise and skip the samples.



Front Key Functions

Users can set the ☒ down key of front panel to be the functions such as Relative PV(Tare) **FELPU** / PV Hold **PuHLd** / Reset for maxi(mini) hold **ArSt** / Reset for relay energized latch **YrSt**.


Ex. The [dRPEY] function set to be **FELPU** in [INPUT GROUP]. When user presses ☒ Key, the PV will show relative value until press ☒ Key again.

Relay Functions

CS1 series offer the 1 relay output with flexible and versatile functions. They can be programmed in [RELAY GROUP]. Please refer to the description as following;

Relay energized mode Hi / Lo / Hi.HLd / Lo.HLd

- **Hi**: Relay will be energized when $PV > \text{Set Point}$ (Fig.1-①)
- **Lo**: Relay will be energized when $PV < \text{Set Point}$ (Fig.1-②)




• Hi.HLd (Lo.HLd)

The relay energized and latched function is for electrical safety and human protection.

For example, a current meter installed for over current alarm of motor. Generally, over current of motor caused by over load, mechanical dead lock, aging of insulation and so on. In the case of alarm of meter, if the user doesn't figure out the real reason and re-start the motor. It may damage the motor. The function is designed that must be manual reset the alarm after checking out and solving the issue. It's very important idea for electrical safety and human protection.

If the PV Higher (or lower) than set-point, the relay will be energized and latch until manual reset by from key in [USEr LEuEL].



■ Start delay band and Start delay time

The functions have been designed for,


1. To avoid alarm for the starting current of inductive motor(6 times of rated current).
2. If the [r_y _nd] relay energized mode has been set to be [Lo] (Lo) or [Lo.HLd] (Lo & latch), the relay will be energized, when the meter is power on and no input due to the "0" display. User can set a band and delay time to inhibit the energized of relay.

• Start band:(Fig.2-①)

Settable range from 0~9999 Counts

• Start delay time: (Fig.2-②)

Settable range from 0.0(second)~9(minutes)59.9(seconds);



■ Hysteresis(Fig.3-①)

Settable range from 0~9999 Counts

The function is to avoid the relay on and off frequently, when the display value is swing near by the set point. The typical application is to control a compressor. User can set a band to prevent the relay on and off frequently.

■ Relay energized delay(Fig.3-②)

Settable range from


0.0(second)~9(minutes)59.9(seconds);

The function is to avoid the miss action caused by noise. Sometime, the display value will swing caused by spark of contactor. User can set a period to delay the relay energized.

■ Relay de-energized delay(Fig.3-③)

Settable range from

0.0(second)~9(minutes)59.9(seconds)



■ Analogue Output Functions

Please specify the output type either a 0~10V or 4(0)~20mA in ordering. The output low and high can be programmable which it's related to various display values. Reverse slope output is possible by reversing point positions.

■ [RoL5]


Settable range: -19999~+99999;

Setting the Display value Low to versus output range Low(as like as 4mA in [R4-20]).

■ [RoH5]

Settable range: -19999~+99999;

Setting the Display value High to versus output range High(as like as 20mA in [R4-20])




*The range between [RoH5] and [RoL5] should be over 20% of span minimum; otherwise, it will reflect the less resolution of analogue output.

■ High Limited for Analog Output

Settable range: 0.00~110.00% of output High;

User can set the high limit of output to avoid destroying the receiver or protection system.



■ Fine Zero & Span Adjustment for Analog Output

Users can get Fine Adjustment of analogue output by front key on the meter. Please connect standard meter to the terminals of analogue output. To press the front key(up or down key) of meter for adjusting and checking the output.

- **[AoZro]: Fine Zero Adjustment for Analog Output;**
 Settable range: -38011~27524;
- **[AoSPn]: Fine Span Adjustment for Analog Output;**
 Settable range: -38011~27524;

■ RS 485 Communication


CS1 series can be used as Remote Terminal Unit (RTU) for monitoring and controlling in a SCADA (Supervisor Control And Data Acquisition) system.

- **Protocol:** ModBus RTU Mode
- **Baud Rate:** Programmable 1200/2400/4800/9600/19200/38400
- **Data Bits:** 8 bits
- **Stop Bits:** Programmable 1 bit or 2 bits
- **Parity:** Programmable Even / Odd / None
- **Device Number:** Settable 1~255



■ Remote Display function

CS1 series has been built in an innovation function call remote display function.

In past, The meter normally receive 4~20mA or 0~10V from AO card or BCD card of PLC. We support a new solution by RS485 remote display function so that can save cost of AO and wiring into PLC.




ORDERING INFORMATION




INSTALLATION


Please check the specification, wire diagrams and functions on the label of the meter before installation.



Dimensions & Panel Cut Out




Installation



Wiring Diagram

Connector


10A 300Vac, M2.6, 16~22AWG,
Max torque: 5Kg-cm
Please use cord end terminal.




Please check the voltage of power supplied first, and then connect to the specified terminals. Herein, recommended that power supplied to the meter with protection by a fuse or circuit breaker.

For input, RS485 wiring, Herein recommended to use twin with shielding wire.


Power Supply




RS485 Communication Port



【 CS1-RL RPM/Linearly Line Speed/Freq.Controller 】



Sensor input connection




Please change the dip-switch on rear of meter to match the input mode and level.

D-S	1	2	3	4	5
NPN	ON				
PNP		ON			
M.C.	ON				ON
5V _r					
12V _r			ON		
24V _r				ON	


D-S is on when it is in down site.

【 CS1-F Frequency Controller 】



■ OPERATIONS

■ Front Panel



- **Engineer Label:** over 80 types.

■ **88888** Numeric Screens

0.8"(20.0mm) red high-brightness LED for 5 digital present value.

■ I/O Status Indicators

- **Relay Energized:** 1 square red LED
RL1 display once Relay 1 has been energized;
- **RS485 Communication:** 1 square orange LED
COM will flash when the meter is receive or send data, and **COM** flash quickly means the data transient quicker.
- **Max/Mini Hold indication:** 2 square orange LEDs
M.H displayed: To display function which expressed it has been selected in Maximum or Minimum Hold function.

■ Stickers:

Each meter with a sticker to describe what are the functions and engineer label enclosure.

Functions stickers

HH	HI	LO	LL	D.L	D.H	DO	D.H	M.H	Tare
GO	Hi.H	Lo.H	R.PV	R.RS	M.RS	PV.H	BK1	BK2	BK3
DI	RST	DO1	DO2	DO3	DO4	DI1	DI2	DI3	

- **Relay energized:**
Hi Hi Energized **Lo** Lo Energized
Hi.H Hi Energized & Latch
Lo.H Lo Energized & Latch
- **Front key functions:**
PV.H PV Hold **Tare** Tare **DI** Digital Input
M.RS Maximum or Minimum Reset
R.RS Reset fo Relay Latch

- **Operating Key:** 4 keys for **ENTER** (Function) / **ESC** (Shift) / **UP** key / **DOWN** key

■ Pass Code:

Settable range:0000~9999;

User must key-in the exactly pass cord for access to **[Programming Level]**. Otherwise, the meter will return to measuring page. If user forget the pass code, please contact with your service window.

- **Function Lock:** There are 4 levels programmable.

- **none (None):** no lock at all. User can access to all level for checking and setting.
- **USER (User Level):** User Level lock. User can access to User Level for checking, but can not setting.
- **ENG (Programming Level):** Programming level lock. User can access to programming level for checking, but can not setting.
- **ALL (ALL):** All lock. User can access to all level for checking but can not setting.

■ Front Key Function

The **ENTER** Key can be set to be function as like as **Relative PV(Tare) / PV Hold / Reset for maxi(mini) hold / Reset for relay energized latch.**

Ex. The **[REL.PV]** function set to be **REL.PV** in **[INPUT GROUP]**. When user presses **ENTER** Key, the PV will show relative value until press **ENTER** Key again.

■ Error Masage

BEFORE POWER ON, PLEASE CHECK THE SPECIFICATION AND CONNECTION AGAIN.

SELF-DIAGNOSIS AND ERROR CODE:

DISPLAY	DESCRIPTION	REMARK
	Display is positive-overflow (Signal is over display range)	(Please check the input signal)
	Display is negative-overflow (Signal is under display range)	(Please check the input signal)
	ADC is positive-overflow (Signal is higher than input 120%)	(Please check the input signal)
	ADC is negative-overflow (Signal is lower than input -120%)	(Please check the input signal)
	EEPROM occurs error	(Please send back to manufactory for repaired)
	Calibrating Input Signal do not process	(Please process Calibrating Input Signal)
	Calibrating Input Signal error	(Please check Calibrating Input Signal)
	Calibrating Output Signal do not process	(Please process Calibrating Output Signal)
	Calibrating Output Signal error	(Please check Calibrating Output Signal)

■ Operating Key:

*Please access to the Engineer Level to check and set the parameters when users start to run the meter


■ Operating Key: 4 keys for Enter(Function) / Shift(Escape) / Up key / Down key


■ The meter has desgined operation similar as PC's and . In any page, press key means "enter" or "confirm setting", and press key means "escape()" or "shift".

■ In Engineer Level, the screen will return to Measuring Page after do not press any key over 2 minutes, or press for 1 second.

	Function Index	Setting Status
(=) Enter/Fun key	(1) In any page, press to access the level or function index (2) From the function index to access setting status	(3) Setting Confirmed, save to EEProm and go to next function index
(=) Shift key	(1) In measuring page, press for 1 second to access user level. (2) In function index, press for 1 second to go back upper level. (3) In function group index, press for 1 second to go back measuring page	(4) In seting status, press to Shift the setting position. (5) In seting status, press for 1 second to abort setting and go back this function index.
(=) Up key	(1) In function index, press to go back to previous function index	(2) In setting status for function, press to select function (3) During number Setting, press can roll the digit up
(=) Down key	(1) In Function Index Page, press will go to the next Function Index Page.	(2) In setting status for function, press to select function (3) During number Setting, press can roll the digit down.

■ OPERATING DIAGRAM:





A-4	FACtEr	FACtEr: Factor of display value 0.001~+9.999	10000	▼	▲
A-5	PuSPn	PuSPn: Fine high point adjustment for PV display -19999~+29999	0	▼	▲
A-6	SCLEr	SCLEr: Clear fine high points adjustment for PV display YES / NO	no	▼	▲
A-7	dSPLY	dSPLY: Display function for PV screen Pu / hAnHd / nARyHd / F5485	Pu	▼	▲
A-8	LoCUT	LoCUT: Low cut the PV -19999~+29999	0.00	▼	▲
A-9	ItOnD	ItOnD: Input time out mode AUto / hAnUL	AUto	▼	▲
A-10	ItO	This function will be shown, once user select hAnUL in [ItOnD] ItO: The time of input time out 0.0sec~999.9sec	0.0	▼	▲
A-11	rAnGE	rAnGE: Display range mode AUto / SEt / hAnUL ※ When by the RS485 read present value(PV).can only choose hAnUL	AUto	▼	▲
A-12	AUG	AUG: Average update for PV 1(None)~99times	5	▼	▲
Next Page					

B-6	rYIFd	rYIFd: Relay 1 de-energized delay time 0:00.0~9(m):59.9(s)	0000	▼	▲
-----	-------	---	------	---	---

D-6	PSCLEr	PSCLEr: Clear the fine zero/span adjustment for analogue output nonE / PuSPn / botH	nonE	▼	▲
D-7	RoLnt	RoLnt: Analogue output high limit 0.00~110.00%	110.00	▼	▲

↑	A-13	dfilt	0	dfilt: Digital filter 0(None)/1~99times
		▼	▲	
	A-14	dnkey	none	dnkey: Down key function none / FLPw / PwHld / nrSt / FySt
		▼	▲	
	A-15	PCode	0000	PCode: Password setting for access to programming level 0000~9999
		▼	▲	
	A-16	FLoCk	none	FLoCk: Function level lock none / USER / EnG / ALL
		▼	▲	

■ Operating Steps:

■ User Level

INDEX		FUNCTION DESCRIPTION	PARAMETERS & SETTING	SET
POWER ON		Please check the specification and wiring diagrams firstly.		
88888		Self-diagnosis (LED All bright)		
↓				
[5 L]		Model [5 L]: RPM/Linearly Line Speed/ Frequency [5 F]: Frequency		
↓				
uEr 14		Firmware version		
↓				
16888		Measuring Page Press  for 1 second to access [User Level]		
0-0-1	 	This page will show out, when [dSPly](step A-7) function has not set to be  . Pu(Pv): Present Value;	Press  for 1 second return to Measuring Page	
0-1	 	rY 1SP (rY1.SP): Relay 1 Set-point Please confirm the energized mode of relay 1 before setting.	Settable range: 0~99999  Shift  Up  Down  Enter	
0-2	 	rY 5t (rY.rSt): Reset for energized latch of Relay; If the [rY 1.Sd](step B-3) set to be  or  , and the present value(PV) reach to the condition of relay energizing, the relay will be energized and latching. At mean time, user can reset the relay latching in here.	Programmable:  /   (Yes): reset the relay latching.  (No): abort to reset the relay latching.  &  Selection  Enter Be careful, the relay has been energizing and latching, if the PV still reach to the condition of relay energized, even user had set here to reset the relay latching.	
0-3	 	n n (Min): the Minimum value of PV saving; The meter will save the minimum of PV during power on, until reset in [n r 5t](step 0-5). It will save newest minimum PV after reset.	Review only	
0-4	 	n R4 (Max): the Maximum value of PV saving; The meter will save the maximum of PV during power on, until reset in [n r 5t](step 0-5). It will save newest maximum PV after reset.	Review only	
Next Page				








	rSt (M.rSt): reset the saved value of Maximum & Minimum; The values of maximum and minimum can be reset in here. It will save newest maximum and minimum after reset.	Programmable: YES / no YES(Yes): to reset the saved value of maximum and minimum. no(No): abort to reset the saved values of maximum and minimum. ▲&▼ Selection FUN ENT Enter	
	Model of the meters CS LrL: RPM/Linearly Line Speed/ Frequency CS IF: Frequency uEr 1.4(Ver 1.4): Firmware version	Review only It will be announced in our website www.adtek.com.tw , when it had been versions updated.	
	Return to the first page Press ◀ for 1 second to back to Measuring Page in any page.		




■ Programming Level









INDEX	FUNCTION DESCRIPTION	PARAMETERS & SETTING	SET
	MEASURING PAGE		
	Enter the pass code to access Programming Level Default:1000	If user wants to change the pass code, please go to step A-15 to set. Please remind the new pass code.	
	Press ◀ for 1 second to back Measuring Page		
GROUP inPUt INPUT GROUP PRESS FUN ENT TO ACCESS	GROUP rELAY RELAY GROUP PRESS FUN ENT TO ACCESS	GROUP Ro ANALOGUE OUTPUT GROUP PRESS FUN ENT TO ACCESS	GROUP r5485 RS485 GROUP PRESS FUN ENT TO ACCESS

Input Group

INDEX		FUNCTION DESCRIPTION	PARAMETERS & SETTING	SET
INPUT GROUP		INPUT GROUP INDEX PAGE	In following pages, press for 1 second to back INPUT GROUP INDEX PAGE.	
A-1	 PutYP LnSPd rPn 	PutYP: PV type selection The meter has designed for multi-purpose. User can set the display purpose in [PutYP] of [INPUT GROUP] such as [LnSPd](Linearly Line Speed), [rPn](RPM), [rPS](RPS), [Hz](Hz), [kHz](kHz). The meter will show the relation parameters as below,	Programmable: [LnSPd]:Linearly Line Speed; [rPn]:RPM(Rotation/Minute) [rPS]:RPS(Rotation/Second) [Hz]:Hz(Frequency) [kHz]:kHz(Frequency) Selection Enter	
A-2-1	 PPr 9999 	This function will be shown, once user selects [rPn] / [rPS] or [LnSPd] in [PutYP] PPr: Pulse/rotation setting	Settable range: 1~9999 Shift Up Down Enter	
A-2-2	 EU unit h/min Yd/min 	This function will be shown, once user selects [LnSPd] in [PutYP] EU unit: Engineer Unit of linearly line speed	Programmable: [h/min] / [cm/min] / [Yd/min] / [Ft/min] [h/min](M/min): Meter/Minute [cm/min](CM/min): Centimeter/Minute [Yd/min](Yd/min): Yard/Minute [Ft/min](Ft/min): Feet/ Minute Selection Enter	
A-2-3	 d.Ant 0.1000 9.9999 	This function will be shown, once user selects [LnSPd] in [PutYP] d.Ant: Diameter of rotor	Settable range: 0.0001~9.9999M Shift Up Down Enter	
A-3	 PudP 0 00000 	PudP: Decimal Point setting; There are two meaning as below, 1.The setting of decimal point is for set-point of relay energized level, when user sets to be [RUto] in [rRnGE] function. 2.The setting of decimal point is for display value and set-point of relay energized level, when user sets to be [hRnUL] or [SEn] in [rRnGE] function.	Programmable: 0 / 00 / 000 / 0000 / 00000 Selection Enter	
A-4	 FAcEr 1000 9.999 	FAcEr: Factor of display value Display = Value of math with setting x Factor The display can be proportioned by factor.The typical application is compensation for gear ratio.	Settable range: 0.001~9.999 Shift Up Down Enter	
Next Page				

A-5  PuSPn 0 20000 Nest Page	PuSPn(Pv.SPn): Fine high point Adjustment for PV display; For Span of PV, users can get the "Fine Adjustment" by front key. It's an easy way to "Just Key-In" the value that the user want to show in the current input signal. Especially, the [PuSPn] is not only in span of PV, but also any higher point for [PuSPn]. The meter will linearize for full scale.	Settable range: 0~99999 ◀Shift ▲Up ▼Down ▶FUN ENT Enter 
A-6  SCLr no YES Nest Page	SCLr (S.CLr): Clear Fine High points Adjustment for PV display;	Programmable: no / YES no(No): Do not clear the fine High adjustment. YES(YES): To clear the fine High adjustment. ▲&▼Selection ▶FUN ENT Enter
A-7  dSPLY Pu RS485 Nest Page	dSPLY(dSPLY): Display Function for PV screen When the [dSPLY] function set to be RS485, At meantime, the display is no longer express the input signal. The PV screen will show the number from RS485 command & data. The data(number) will be same as PV that it will compare with set-point, analogue output and ECI functions so that is to control analogue output, relay energized and so on.	Programmable: Pu / Mini.H / MAX.H / RS485 Pu(PV): shows PV Mini.H(Mini.H): Minimum Hold of PV MAX.H(MAX.H): Maximum Hold of PV RS485(RS485): Remote displayed from RS485 command of master. ▲&▼Selection ▶FUN ENT Enter
A-8  Lo.Cut 0 00 100 Nest Page	Lo.Cut (Lo.Cut): Low Cut the PV If the setting value is positive, it means the PV is in the range of absolute value will be 0; $PV \leq \text{Setting value}$, the display will be 0. If the setting value is negative, it expressed the PV will be X which it's under the setting value; $PV < \text{Setting value}$, the display will be X(Setting value).	Settable range: -19999~+29999 ◀Shift ▲Up ▼Down ▶FUN ENT Enter Low Cut set to be +0.50  Low Cut is set for 0.50, if the PV is from -0.50~+0.50, that display will be 0. Low Cut set to be -0.10  Low Cut is set for -0.10, if the PV is under (≤ -0.10), that display will be -0.10.
Next Page		





A-9 		t.o.td: Input Time Out Mode; In the case of low frequency, the meter can not to identify that is low frequency and no input until the next pulse input. Sometimes, it takes a long period. The meter builds in a time out function to cut out the display to be "0".	Programmable: AUto / hAnUL AUto(Auto): The display will be "0", once the next pulse doesn't input during the time that gave by formula of meter's firmware. Gerenally, the auto time out is 4 times of last frequency of input. hAnUL(Manual): There is a period named t.o(input time out) can be set from 0.0sec~999.9sec. The display will be "0", once the next pulse doesn't input during the setting time. ▲&▼Selection FUN ENTEnter
A-10 		This function will be shown, once user set to be hAnUL in [t.o.td] function t.o: the time of Input Time Out;	Settable range: 0.0 sec~999.9sec ◀Shift ▲Up ▼Down FUN ENTEnter
A-11 		rAnGE: Display Range Mode ※ When by the RS485 read present value(PV), can only choose hAnUL	Programmable: AUto / SEn / hAnUL AUto(Auto range): The decimal point will be auto changed according to the input frequency so that keep the display in the highest resolution. SEn(Semi-Auto range): The decimal point will be auto changed according to the input frequency to keep the display in the highest resolution, but it must be under setting position of decimal point. It's possible to show "ouFL(overflow)", if the input frequency is over the display range. hAnUL(Manual range): The decimal point will be fixed according to the setting of [dP]. The meter will show ouFL(overflow), once the input goes over the frequency that is relative 99999. ▲&▼Selection FUN ENTEnter
Next Page			

A-12 		AvG (AvG): Average update for PV Jittery Display caused by the noise or unstable signal. User can set number to average the readings to get smoothly display. The meter's sampling is 15 cycles/sec. If the [AvG](Average) set to be the 3, which means the meter is sampling 3 readings, and calculating the average to update display once. At meantime, the display update will be 5 times/sec.	Settable range: 1(no function)~99 times ◀Shift ▲Up ▼Down Enter	
A-13 		dF iLt (d.FiLt): Digital filter The digital filter can reduce the magnetic noise or EMI in the field. If the values of samples are over digital filter band(fix in firmware and about 5% of stable reading) 3 times (Digital Filter set to be 3) continuously, the meter will admit the samples and update the new reading. Otherwise, it will be as treat as a noise and skip the samples.	Settable range: 0(no function)/1~99 times. ◀Shift ▲Up ▼Down Enter	
A-14 		dnKEY (dn.key): Down key function Users can set the ▼down key of front panel to be the functions as like as Relative PV(Tare) / PV Hold / Reset for maxi(mini) hold / Reset for relay energized latch.	Programmable: nonE (None): No function PvHLd (PV.HLd): PV Hold rELPv (Rel.PV): Relative PV(ΔPV) / Tare M.rSt (M.rSt): Reset for Maximum or Minimum Hold. rY.rSt (rY.rSt): Reset for Relay energized & latch. ▲Up ▼Down Enter	
A-15 		P.Code (P.Code): Pass Code setting for access to programming level Please remind and write down the new pass code so that access to programming level.	Settable range: 0000~9999 ◀Shift ▲Up ▼Down Enter	
A-16 		F.LoCk (F.LoCk): Function level Lock There are 4 levels programmable for lock that the function is to avoid mis-setting.	Programming: nonE (None): no lock at all. User can access to user level for checking and setting. USEr (User Level): User level lock. User can access to user level for checking, but can not setting. EnG (Programming Level): Programming level lock. User can access to programming level for checking, but can not setting. ALL (All Level): All lock. User can access to all level for checking, but can not setting. ▲&▼Selection Enter	




■ **Relay Group** (The group will not be displayed except the relay function is to be specified)

INDEX		FUNCTION DESCRIPTION	PARAMETERS & SETTING	SET
RELAY GROUP		RELAY GROUP INDEX PAGE	In following pages, press ◀ for 1 second to return the RELAY GROUP INDEX PAGE.	
B-1 rY.Sb		rY.Sb(rY.Sb): Start band of Relay energized The functions have been designed for, 1. To avoid alarm for the starting current of inductive motor(6 times of rated current). 2. If the rY.nd relay energized mode has been set to be Lo(Lo) or Lo.HLd(Lo & latch), the relay will be energized, when the meter is power on and no input due to the "0" display. User can set a band and delay time to inhibit the energized of relay.	Settable range: 0~9999 digits ◀Shift ▲Up ▼Down FUN ENT Enter	
B-2 rY.Sd		rY.Sd(rY.Sd): start delay time for Relay energized	Settable range: 0:00.0~9(M):59.9(S) ◀Shift ▲Up ▼Down FUN ENT Enter	
B-3 rY.nd		rY.nd(rY1.Md): Relay 1 energized mode	Programmable: oFF(Off): Turn off the Relay and indication LED. Lo(Lo): Low Level Energized; Relay will energize when PV < Set-Point. Hi(Hi): High Level Energized; Relay will energize when PV > Set-Point. Hi.HLd(Hi.HLd)/Lo.HLd(Lo.HLd): High / Low Level energize and latch; When the PV Higher (or lower) than set-point, the relay will be energized and latch until manual reset by from key in [User Level], front key function or terminals of E.C.I. closed do(DO): Digital Output; Relay is energized by RS485 command directly, and no longer to compare with set-point of relay. ▲&▼Selection FUN ENT Enter	

Next Page

B-4  0.0 5000 Nest Page	rY lHY (rY1.HY): Relay 1 Hysteresis The function is to avoid the relay on and off frequently, when the display value is swing near by the set point. The typical application is to control a compressor. User can set a band to prevent the relay on and off frequently. Energized / De-energized Delay & Hysteresis 	Settable range: 0~19999 digits ◀Shift ▲Up ▼Down FUN ENT Enter
B-5  0.000 9.999 Nest Page	rY lrd (rY1.rd): Relay 1 energized delay time	Settable range: 0:00.0~9(M):59.9(S) ◀Shift ▲Up ▼Down FUN ENT Enter
B-6  0.000 9.999 Nest Page	rY lFd (rY1.Fd): Relay 1 de-energized delay time	Settable range: 0:00.0~9(M):59.9(S) ◀Shift ▲Up ▼Down FUN ENT Enter

Analogue Output Group (The group will not be displayed except the AO function is to be specified)

INDEX	FUNCTION DESCRIPTION	PARAMETERS & SETTING	SET
Ao Group FUN ENT	AO GROUP INDEX PAGE	In following pages, press ◀ for 1 second to return the AO GROUP INDEX PAGE.	
D-1  Ao.tYP R4-20 0.0-10 Nest Page	Ao.tYP (Ao.tYP): Analogue Output type and range selection; Analogue output type had been fixed in mA or V as customer ordering requested. Therefore, the type selection is for ranges in same type(Voltage or Current).	Programmable: Voltage Output: 0.0-10 (0~10V) / 0.0-5 (0~5V) / 0.1-5 (1~5V) Current Output: 0.0-10 (0~10mA) / 0.0-20 (0~20mA) / R4-20 (4~20mA) ▲&▼ Selection FUN ENT Enter	
D-2  Ao.LS 0.0 5000 Nest Page	Ao.LS (Ao.LS): the Low point is relative to Analogue Output low; To set the lower display value to versus output range low(as like as 4mA in R4-20) Ex. Ourput range set to be R4-20 (4~20mA) is relative to display 0~199.99. User can set the [Ao.LS] (Ao.LS) to be 5000. At meantime, the output signal will be 4mA when the present value is 50.00.	Settable range: -19999~99999 ◀Shift ▲Up ▼Down FUN ENT Enter 	
Next Page			


D-3	R0.HS 19999 15000 ↓ ↑ Next Page According to the setting of H.LSC	R0.HS (Ao.HS): the High point is relative to Analogue Output high; To set the higher display value to versus output range high(as like as 20mA in R4-20) Ex. Ourput range set to be R4-20 (4~20mA) is relative to display 0~199.99. User can set the [R0.HS] (Ao.HS) to be 15000. At meantime, the output signal will be 20mA when the present value(PV) is 150.00.	Settable range: -19999~99999 ◀Shift ▲Up ▼Down Enter
D-4	R0.Zro 00000 17233 ↓ ↑ Next Page	R0.Zro (Ao.Zro): Fine Zero Adjustment for Analog Low Output; Users can get Fine zero Adjustment for analogue output by front key. Please connect standard meter to the terminal of analogue output. To press the front key(up or down key) to adjust and check the output of meter.	Settable range: -38011~27524 ◀Shift ▲Up ▼Down Enter
D-5	R0.SPn 00000 32167 ↓ ↑ Next Page	R0.SPn (Ao.SPn): Fine Span Adjustment for Analog high Output; Users can get Fine span Adjustment for analogue output by front key of the meter as like as [R0.Zro] (Ao.Zro).	Settable range: -38011~27524 ◀Shift ▲Up ▼Down Enter
D-6	Z.S.Clr nonE botH ↓ ↑ Next Page	Z.S.Clr (Z.S.Clr): Clear the Fine Zero / Span Adjustment for Analog Output	Programmable: nonE(None): Do not clear R0.Zro(Ao.Zro): Clear low adjust R0.SPn(Ao.SPn): Clear high adjust botH(both): Clear low & high adjust ▲&▼Selection Enter
D-7	R0.LMt 11000 10000 ↓ ↑ Next Page	R0.LMt (Ao.LMt): Analog Output High Limit Set Scaling: [L0.SC]: 000, [H.SC]: 19999; Output: [R0.LS]: 5000 (Display value Low); [R0.HS]: 15000 (Display value High); [R0.LMt]: 8000 % (of Output Range) SCALE [H.SC] 19999 [R0.HS] 15000 10000 [R0.LS] 5000 [L0.SC] 000 0.00% 50.00% 80.00% 100.00% OUTPUT [R0.LMt]	Settable range: -0.00~ 110.00% of FS ◀Shift ▲Up ▼Down Enter

■ RS485 Group (The group will not be displayed except the RS485 function is to be specified)

INDEX		FUNCTION DESCRIPTION	PARAMETERS & SETTING	SET
RS485 GROUP FUN ENT ↓		RS485 GROUP INDEX PAGE	In following pages, press  for 1 second to return the RS485 GROUP INDEX PAGE.	
E-1 AdRES 001 255 ↓ ↑ FUN ENT Next Page	FUN ENT 001 255 ↓ ↑ FUN ENT Next Page	AdRES (Adress): Device number of the meter.	Settable range: 1~255  Shift  Up  Down  Enter	
E-2 bAUd 9600 38400 ↓ ↑ FUN ENT Next Page	FUN ENT 9600 38400 ↓ ↑ FUN ENT Next Page	bAUd (bAUd): Baud rate	Programmable: 1200 / 2400 / 4800 / 9600 / 19200 / 38400  &  Selection  Enter	
E-3 Pr itY nStb.2 EvEn ↓ ↑ FUN ENT Next Page	FUN ENT nStb.2 EvEn ↓ ↑ FUN ENT Next Page	Pr itY (PritY): Parity	Programmable: nStb.1 (n.Stb.1): None, 1 stop bit nStb.2 (n.Stb.2): None, 2 stop bit odd (odd): odd EvEn (EvEn): Even  &  Selection  Enter	

■ TROUBLE SHOOTING

Display Issue:

PROBLEM	CHECKING LIST	REMEDY
Display shows 	1. To inspect the input range of meter whether did match with range in the field or not?	A. The input range of CS1-RL(F) is 0.01~100kHz(optional: 0.01~140kHz). Please make sure input of field is between this range. B. Please check the setting of [RLGE] function whether did it correct or not? If user sets the [RLGE](A-11)function to be  or  , the display maybe shows  , when the input frequency is over so that the display is over  (with decimal point). Please change the setting to  . The decimal point will be auto changed according to the input frequency.
Display shows  and didn't change	1. To inspect whether did the wires connecting correct and secure or not?	A. Please checks carefully the connection diagram of label on the meter. There are 3 terminals for signal(+), signal(-) and excitation power supply(+). Please confirm that are correct. B. Please uses the terminals(cord end terminal) to avoid the risk of insecure.
	2. To inspect whether did the amplitude of pulse correct or not?	A. Please check the auxilliary power of sensor and output level. The input amplitude of meter can be changed by the dip switches on rear of meter. Please refer to the drawing as below,  *Remark: The meter builds in a excitation power for sensor that can not be changed. Please specified in ordering code.
Incorection display value or out of accuracy	1. To inspect the settings of relation parameters whether did it correct or not?	A. Please check the  (A-01) whether did it correct or not?  (Linearly Line Speed),  /  (Rotation Speed),  /  (Frequency) Linearly Line Speed:  (A-2-1) /  (A-2-2) /  (A-2-3) Rotation Speed:  (A-2-1) B. Please check the  (A-04) whether did it correct or not?
	2. To inspect the fine adjustments of PV whether did it changed or not?	Please check the  (A-05) in [LPUL GROUP] whether did the values correct or not? The  can be cleared in  (A-06).
Jittery Display	1. To inspect the input signal and it jittery.	A. Please check the installation of sensor whether did it balance and stable or not? The vibration of sensor will make the signal unstable. B. If the input signal is jittery continuously, please set higher value in [RLGE](A-12). C. If the input signal is jittery uncertain period that caused by the inductive load actions, please set higher value in  (A-13). D. Please does not lay the wires of input together with high-voltage lines or power lines. As a general rule, wire the meter in a separate system, use an independent metal conduit, or use shielded cable.

	2.To inspect the input signal and it is stable.	A.Please try to set higher value in [R0G](A-12). B.Please try to set higher value in [dF L E](A-13). C.Please connects a isolation transformer as close as meter in power lines.
Display shows "-----"	To inspect display function [dSPLY]. It's maybe to be set to F5485	Please check the [dSPLY](A-07) in [INPUT GROUP] and change the function setting from F5485 to PU .
display value doesn't change	1.To inspect display function [dSPLY]. It's maybe to be set to hARHd (maximum hold) or h mHd (minimum hold)	A.Please check the [dSPLY](A-07) in [INPUT GROUP] and hange the function set from hARHd or h mHd to PU .
	2.To inspect Down key function [dNDEY]. It's maybe to be set to PUHLd .	A.Please check the [dNDEY](A-14) in [INPUT GROUP] and change the function setting from PUHLd to PU .

Relay Output Issue:

PROBLEM	CHECKING LIST	REMEDY
The parameters of Relay doesn't shown	Check if the label of meter for detail specification.	A.Please check the product number and output(O/P:_____) description again for confirmation the relay output is specified or not? B.Please send back to our sales window, or order another meter with relay function.
Relay cans not action.	The relay energized, but square red LED doesn't bright	
	1.Check the energized mode	Please check the [rY h d](B-03) in the [RELAY GROUP]
	2.Check the delay time and delay band in the start delay function.	Please check whether did the [rY5b](B-01) is too wide and [rY5d](B-02) is too long in [RELAY GROUP] or not?
	3.Check the energized delay time	Please check whether did the [rY L d](B-05) is too long in [RELAY GROUP] or not?
	The relay energized, but square red LED dose bright	
	1.Check the wiring of relay output	According to the label of meter, please check again the connection wire of relay. Be careful to check the number of relay is matching the setting.
	2.Check the voltage of supply power	

Analogue Output Issue:

PROBLEM	CHECKING LIST	REMEDY
Incorection analogue output value or out of accuracy	1.To inspect the output signal type (V/A/mA..) or range of meter whether did match with signal in the field or not?	A.Please check the product number and output(O/P:_____) description again for confirmation the analogue output is specified or not? ; B.Please confirm the output type is correct and check the range in [R0tYP](D-01) of [Ro GROUP]
	2.Check the Analogue output high and low setting.	A.Please check the [R0L5](D-02) and [R0H5](D-03) in [Ro GROUP].

PROBLEM	CHECKING LIST	REMEDY
Jittery Analogue Output	Analogue output is according to the display	
	1.Check if the display is jittery	A.If the input signal was jittery continuously, please set higher value in [R00](A-12). B.If the input signal is jittery uncertain period that caused by the inductive load actions, please set higher value in [dF .L t](A-13). C.Please does not lay the wires of input together with high-voltage lines or power lines. As a general rule, wire connecting with the meter has to be in a separate system, use an independent metal conduit, or use shielded cable.
	2.Check if the display is stable	Please do not lay the wires of output together with high-voltage lines or power lines. As a general rule, wire connecting with the meter has to be in a separate system, use an independent metal conduit, or use shielded cable.
RS485 Communication Issue:		
PROBLEM	CHECKING LIST	REMEDY
Can not link	Check if the square orange LED of RS485 dosen't bright.	A.Please check the [Rd r E5](E-01) \ [bAUd](E-02) and [P r t y](E-03) in [r 5485 C oUP] that both have to match the Host. B.Please check the wiring A(+) and B(-) are correct or not? C.If user uses a converter (RS485/RS232 or RS485/USB..), please check the setting and wiring of converter is correct. D.Please check the protocol of host is Modbus RTU Mode
Reply wrong data from the meter	1.Check if the square orange LED of RS485 dose bright, but no reply.	A.Please confirms the CHECH SUM program is correct. B.Please check the interval of each command has to over 3.5byte.
	2.Check if the square orange LED of RS485 dose bright, but reply Error.	A.Please check the address table of RS485 to make sure that is right address. B.Please checks the start address and data format are correct. C.Please do not lay the wires of RS485 together with high-voltage lines or power lines. As a general rule, wire the meter in a separate system, use an independent metal conduit, or use shielded cable.

■ RS485 MODBUS RTU MODE

■ Modbus RTU Mode protocol

1. Function 03H (Read Holding Registers)

Request Data Frame; EX: Read the data of display value(0000H starts from 1 Word)

SLAVE Address	FUNCTION	Starting Address Hi	Starting Address Lo	No. of Word Hi	No. of Word Lo	CRC Lo	CRC Hi
01H	03H	00H	00H	00H	01H	84H	0AH

Response Data Frame; EX: The response value is "0"

SLAVE Address	FUNCTION	Byte count	Data Hi	Data Lo	CRC Lo	CRC Hi
01H	03H	02H	00H	00H	B8H	44H

Request Data Frame (EX: Continue to request the data of 10 points)

SLAVE Address	FUNCTION	Starting Address Hi	Starting Address Lo	No. of Word Hi	No. of Word Lo	CRC Lo	CRC Hi
01H	03H	00H	00H	00H	0AH	C5H	CDH

Response Data Frame

SLAVE Address	FUNCTION	Byte count	Data(1) Hi	Data(1) Lo	...	...	Data(10) Hi	Data(10) Lo	CRC Lo	CRC Hi
01H	03H	14H	00H	00H	...	...	01H	00H	--	--

2. Writing Command by Function 06H (Preset Single Register)

Request Data Frame

SLAVE Address	FUNCTION Code	Starting Address Hi	Starting Address Lo	Preset DATA Hi	Preset DATA Lo	CRC Lo	CRC Hi
01H	06H	00H	00H	00H	02H	08H	0BH

Response Data Frame

SLAVE Address	FUNCTION Code	Starting Address Hi	Starting Address Lo	Preset DATA Hi	Preset DATA Lo	CRC Lo	CRC Hi
01H	06H	00H	00H	00H	02H	08H	0BH

■ ADDRESS TABLE **Address number are Hexadecimal

■ User level

Name	Address	Range	Explain	Initial	Write/Read	Note
	2 Words					
PV_H*	0000h		Present Value*(High Word)		R	
PV_L*	0001h		Present Value*(Low Word)		R	
PuHLd_H*	0002h		PV Hold*(High Word)		R	
PuHLd_L*	0003h		PV Hold*(Low Word)		R	
min_H*	0004h		The Minimum of PV*(High Word)		R	
min_L*	0005h		The Minimum of PV*(Low Word)		R	
max_H*	0006h		The Maximum of PV*(High Word)		R	
max_L*	0007h		The Maximum of PV*(Low Word)		R	
diameter_H*	0008h	0.0001~9.9999	Diameter of rotor*(High Word)	0000h	RW	
diameter_L*	0009h		Diameter of rotor*(Low Word)	03E8h	RW	
PuSpan_H*	000Ah	-19999~+19999	PV Span*(High Word)		RW	
PuSpan_L*	000Bh		PV Span*(Low Word)		RW	
rs485_H*	000Ch	-19999~+19999	PV controlled by RS 485 command*(High Word)		RW	
rs485_L*	000Dh		PV controlled by RS 485 command*(Low Word)		RW	

■ Programming Level

[Input Group]

Name	Address	Range	Explain	Initial	Write/Read	Note
	1 Word					
dP	000Eh	0~4	Decimal Point of Setting 0: 00000 1: 0000.0 2: 000.00 3: 00.000 4: 0.0000	0000h	RW	
rESErUEd	000Fh					
rESErUEd	0010h					
rESErUEd	0011h					
rESErUEd	0012h					
System Status	0013h		SYSTEM STATUS bit0=1 EEP fail; bit1=1 No Used bit2=1 No Used bit3=1 Analogue Output calibration fail; bit4=1 Analogue Output calibration NG	0000h	R	
̄rSt	0014h	0~1	Reset Maximum & Minimum Value 0:No 1:Yes	0000h	R/W	
Pu.tYP	0015h	0~3	PV Type 0: Linear Speed 1: RPM 2:RPS 3: Frequency	0000h	R/W	
PPr	0016h	1~9999	Pulse per Rotation	0001h	R/W	
FRctr	0017h	0.001~9.999	Factor of compensation	0000h	R/W	
E.Un it	0018h	0~3	Engineer Unit 0: M/min 1: CM/min 2:Yard/min 3: Feet/min	0000h	R/W	
ito.̄d	0019h	0~1	Input Time Out Mode 0: Auto 1: Manual	0000h	R/W	
ito	001Ah	1~9999(0.1 second)	Input Time Out	03E8h	R/W	
rRnGE	001Bh	0~2	Input Range 0: Auto 1: Semi-Auto 2: Manual	0000h	R/W	
S.clr	001Ch	0~1	Clear of PV Span 0: No 1: Yes	0000h	R/W	
Lo.CUt	001Dh	-19999~19999	Low Cut	0000h	R/W	
dSPLY	001Eh	0~3	Display Function 0: PV 1: Min. hold 2: Max. hold 3: RS 485	0000h	R/W	
RuG	001Fh	1~99	Average	0005h	R/W	
d.F ilt	0020h	0~99	Digital Filter	0000h	R/W	
P.CoDE	0021h	0000~9999	Pass Code	03E8h	R/W	
F.LoCk	0022h	0~3	Function Lock 0: None 1: User Level 2: Engineer Level 3: All	0000h	R/W	

[RS485 Group]						
Name	Address	Range	Explain	Initial	Write/Read	Note
AdrES	0023h	1~255	RS485 address	0001h	R/W	
bAUd	0024h	0~5	RS485 baud rate 0: 1200 1: 2400 2: 4800 3: 9600 4: 19200 5: 38400	0003h	R/W	
Pr itY	0025h	0~3	RS485 parity 0: n-8-1 1: n-8-2, 2: odd, 3: even,	0001h	R/W	